



Efficient & Server-X Serisi Dikili Tip 600x1000 Rack Kabin Montaj Kılavuzu ve Talimatları

(Efficient & Server-X Series Free Standing 600x1000 Rack Cabinet Installation Guide and Instructions)

PRODUCT ASSEMBLY
MONTAJ KİTAPÇIGI




- ① ÜST TAVAN-UPPER CEILING
- ② ALT TABAN-LOWER BASE
- ③ BOY DİKME-VERTICAL POLE
- ④ RACK DİKME-RACK VERTICAL POLE
- ⑤ KABLO GEÇİŞ-REAR CABLE TRANSITION
- ⑥ YAN DERİNLİK ATKI-SIDE DEPTH WEFT
- ⑦ YAN ÜST KAPAK-SIDE UP COVER
- ⑧ YAN ALT KAPAK-SIDE DOWN COVER
- ⑨ YAN BÖLME-SIDE MIDDLE FIXED COVER
- ⑩ ARKA KAPAK-REAR COVER
- ⑪ CAMLI ÖN KAPAK-GLASS FRONT DOOR
& PERFORE ÖN KAPAK & PERFORATED



Efficient & Server-X Serisi Dikili Tip 600x1000 Rack Kabin Montaj Kılavuzu ve Talimatları

(Efficient & Server-X Series Free Standing 600x1000 Rack Cabinet Installation Guide and Instructions)




Not: Kabin iŖteđinize gre dikey veya yatay konumda montaj yapabilirsiniz.

Note: You can assemble the cabinet in horizontal and vertical positions according to your wishes.

Efficient & Server-X Serisi Dikili Tip 600x1000 Rack Kabin Montaj Kılavuzu ve Talimatları


(Efficient & Server-X Series Free Standing 600x1000 Rack Cabinet Installation Guide and Instructions)



Efficient & Server-X Serisi Dikili Tip


600x1000 Rack Kabin Montaj Kılavuzu ve Talimatları

(Efficient & Server-X Series Free Standing 600x1000 Rack Cabinet Installation Guide and Instructions)




Efficient & Server-X Serisi Dikili Tip 600x1000 Rack Kabin Montaj Kılavuzu ve Talimatları

(Efficient & Server-X Series Free Standing 600x1000 Rack Cabinet Installation Guide and Instructions)




Efficient & Server-X Serisi Dikili Tip 600x1000 Rack Kabin Montaj Kılavuzu ve Talimatları (Efficient & Server-X Series Free Standing 600x1000 Rack Cabinet Installation Guide and Instructions)



Not: Yan derinlik atkısı 34U ve üzeri kabinlerde kullanılmaktadır.
Note: Side depth weft is used in 34U and above cabinets.

Efficient & Server-X Serisi Dikili Tip 600x1000 Rack Kabin Montaj Kılavuzu ve Talimatları

(Efficient & Server-X Series Free Standing 600x1000 Rack Cabinet Installation Guide and Instructions)



Yan alt ve üst kapakların alt kısmında (K-K)detayında gösterilen kapı sabitleme bükümleri alt tabanda ve yan bölme parçasındaki uygun yarıklara yerleştiriniz. Daha sonra kilitleme işlemini yapabilirsiniz.


Place the cover with fastening bends shown in detail (K-K) on the bottom base and the side partition in the appropriate slots. Then, proceed to perform the locking procedure.

Not: Alt ve üst yan kapaklar sadece 42U 600x1000 ve 42U 800x1000 ölçülerindeki kabinlerde kullanılmaktadır.

Note: The lower and upper side covers are only used for cabinets with dimensions of 42U 600x1000 and 42U 800x1000.

Efficient & Server-X Serisi Dikili Tip 600x1000 Rack Kabin Montaj Kılavuzu ve Talimatları

(Efficient & Server-X Series Free Standing 600x1000 Rack Cabinet Installation Guide and Instructions)



Efficient & Server-X Serisi Dikili Tip

600x1000 Rack Kabin Montaj Kılavuzu ve Talimatları

(Efficient & Server-X Series Free Standing 600x1000 Rack Cabinet Installation Guide and Instructions)

